

TRITON TREATMENTS AL99

What is it? What is it for?

AL99 is and Aluminium Based high quality (>99% pure) treatment for removing phosphate.

Also removes barium and silicate



Skill Level

This product is classified as Basic skill level



Important notes for usage

AL99 should be rinsed thoroughly with RODI prior to use to prevent elevating AL levels in your system water.

AL99 when used in a reactor must NOT be tumbled.



How do I use AL99?

Rinse AL99 prior to use with RODI water until the "fizzing" reaction stops.

AL99 should be used in a reactor capable of flow adjustment to prevent tumbling of the media.

50ml of AL99 per 100L of aquarium water, however in cases of high PO4 levels this can be increased to 100ml AL99 per 100L aquarium water.

Change media every 4 weeks or more regularly if elevating PO4 levels are observed.



Other additional information

If rising AL levels are observed via ICP-OES testing then we recommend alternating PO4 media with a GFO based media. We recommend ROWAphos or Phosban, other low quality PO4 media can add Barium to the water.